

NIST Overview MEMS and Nanotechnology

Michael Gaitan MEMS Project Leader

National Institute of Standards and Technology
Semiconductor Electronics Division
Department of Commerce



Donald Evans Secretary

Secretary
Deputy Secretary



Dr. Samuel Bodman Deputy Secretary

National Oceanic and Atmospheric Administration

Patent and Trademark Office

National
Telecomm. & Info.
Administration

(Other bureaus)

Technology Administration



Phillip Bond Under Secretary



Department of Commerce


National Technical Information Service

Office of Technology Policy


National Institute of Standards and Technology




Dr. Arden Bement Director



Dr. Hratch Semerjian Deputy Director (Acting)



. . .working with industry to develop and apply technology, measurements and standards




NIST Has Two Campuses...

Gaithersburg, MD



Boulder, CO



..and two joint Institutes

CARB University of Maryland



JILA University of Colorado




NIST: A Unique Mission and Assets

NIST's mission is to develop and promote measurement, standards, and technology to enhance productivity, facilitate trade, and improve the quality of life.

NIST Assets Include:

- 3,000 employees
- 1,600 associates
- \$825 million FY 2003 operating budget
- Advanced Technology Program -- \$4 billion in cost-shared partnerships with industry since 1990
- Manufacturing Extension Partnership -- 400 centers nationwide to help small manufacturers
- Baldrige National Quality Award
- NIST Laboratories -- National measurement standards

NIST Advanced Technology Program



- Co-funding of private sector R&D to accelerate the development of highrisk, broadly enabling technologies.
- Auto Body Consortium improved fitting of parts to save money for manufacturers and consumers
- Tissue Engineering new materials to repair damaged ligaments and tendons: several billion dollar impact
- "DNA Chips" new technology for cheap, rapid genetic analysis

www.atp.nist.gov

Manufacturing Extension Partnership

 Nationwide network providing hands-on help to smaller manufacturers to become


globally competitive

Business assistance

- Quality management
- Human resource development
- Financial planning
- Other services

Technical assistance

- E-commerce
- Process improvement
- Plant layout
- Product development
- Energy audits
- Other services



www.mep.nist.gov

Baldrige National Quality Program




- Premier U.S. award for performance excellence and quality achievement.
- Awards in Manufacturing, Service, Small Business, Education, Health Care.
- More than 2 million copies of Criteria for Performance Excellence distributed (not including downloads from Web).



www.baldrige.nist.gov

NIST Laboratories and Technical Staff



Multidisciplinary expertise to develop measurements and standards to enable:

- □ Science
- □ Technology innovation
- □ Trade
- ☐ Public benefit

NIST plans and works in close collaboration with customers:

- □ Industry
- □ Other agencies
- ☐ State and local governments
- Measurement laboratories
- ☐ Standards development organizations

Unique Measurement and Research Facilities





Advanced Measurement Laboratory :

- Unparalleled environmental control
- Nanofabrication Facility
- Completion targeted for 2004

Advanced Chemical Sciences Laboratory

Critical capabilities in nanobiotechnology and analytical chemistry





NIST Center for Neutron Research

 Most versatile neutron facility in the US with over 1750 users annually

http://www.memsalliance.org

MEMS Alliance



An alliance of companies, universities, and government laboratories in the Washington DC metropolitan area. Our mission is to create a group that networks expertise, capabilities, and research to facilitate the development of new applications and commercialization of miniaturization technologies.

www.memsalliance.org

Ma ryland Wa shington DC Vir ginia

MEMS
Microfluidics
BioChips
Microfabrication
Microsystems
Cell Phone on a Chip

An Allicance Of: Companies Universities Government Laboratories

MANA – Mid-Atlantic Nanotechnology Alliance

NIST Products and Services

- Measurement Research
 2,200 publications/year
- Standard Reference Data 90 types available 5,500 units sold/ year
- Standard Reference Materials

 1,300 products available
 31,000 units sold/year
- Calibrations and Tests
 3,000 items calibrated/year
- Laboratory Accreditation
 819 accreditations
- Standards Committees

 440 NIST staff, 970 committees



Strategic Focus Areas

NIST 2010

- ☐ Health Care
- □ Nanotechnology
- ☐ Homeland Security
- □ Information / Knowledge Management



MEMS and Nanotechnology Overview

- Standardization
 - Measurement Methods
 - e-Standards
 - Manufacturing

- Devices for improved measurements
 - NanoBioTechnology
 - Single molecule measurements

Standardization Groups


Task Group Descends On Micro-Technology

An ASTM task group is working with tiny mechanical parts smaller than the width of a human hair. Work on microelectromechanical systems (MEMS) standardization is under way in Task Group E08.05.03 on Structural Films and Electronic Materials, under Subcommittee E08.05 on Cyclic Deformation and Fatigue Crack Formation, in Committee E-8 on Fatigue and Fracture. Scientists experienced in fatigue and fracture and/or creep-process are sought for development of MEMS test methods.

In these tiny systems, barely visible gears, hinges, motors, and other mechanical

components are manipulated by micro-tweezers and probes, and viewed with scanning electron micro-scopes. "Imagine everything in day-to-day life being miniaturized: gears, wheels, motors, turbine engines, everything. My whole fatigue testing machine fits on a silicon chip a few hundred microns square," said Task Group Chairman Chris Muhlstein, a materials scientist in the Materials Science and Engineering Department, University of California, Berkeley.

MEMS are made from combinations of metals, ceramics, and polymers. "The little nozzles on your inkjet cartridge are probably one of the (CONTINUED ON NEXT PAGE)



Smaller than the width of a human hair, microscopic gears of this type are used in polysilicon microengine transmissions, an important application for new ASTM standards. ASTM

Task Group E08.05.03

Est. 1998

Measurement Methods - Residual

Stress, Elastic Modulus

 Micromachine Standardization Forum

Japan's MMC

Est. 2000

Terminology

• SEMI

IMSG - International MEMS Standardization Working Group

Est. 2003

Manufacturing


ASTM STANDARDIZATION NEWS, JUNE 1999 9

Dimensional Measurements of MEMS Test Structures



- NIST Report on measurement of length and strain measurements.
- 3 ASTM Test methods for dimensional and strain measurement are completed.
- A round robin experiment to determine precision and bias is in progress.

e-Standards




On-line hyperlink documents that:


- Provide a guide through the measurement procedure.
- Currently: cantilevers and buckled beams.
- Will provide links for explanations to questions the user might have.
- Will include other information such as web links to other standards, references, and people to contact.

Systems

Commercial Examples




Analog Devices Accelerometer



Texas Instruments
Deformable Mirror Display

Manufacturing



CMOS-Integrated Circuit-Foundry MEMS – *cif*-MEMS

Circuits and Devices:
"Melding Micromachined
Devices with CMOS
Foundries," November
1992

http://www.mosis.org/Products/mems.html

cif-MEMS


- Devices
 - Thermal-Based Elements


Thermal Displays, Microhotplate Gas Sensors, Convective Accelerometers, Flow Sensors, Vacuum Sensors, Microchemical Reactors

- Microwave Elements
 - Spiral Inductors, Coplanar Transmission Lines, Antennas, Resonant Filters, Power Sensors
- Electromechanical Elements

Resonators, Accelerometers, Micro mirrors

Microhotplate Gas Sensors








Semiconductor Electronics Division EEEL

Process Measurements Division CSTL

Convective Accelerometer








http://www.memsic.com

ASIMPS Post-CMOS Micromachining




ASIMPS: AMS 0.6 μm, 3-metal

http://www.ece.cmu.edu/~mems/projects/asimps

Scales


Electronics: Top-Down



Biolotechnology: Bottom-Up

Human DNA 3 billion base pairs 1 meter total length

Nanobiotechnology = Nanofabrication + Biotechnology



Single Molecule Manipulation and Measurement: SM³



Michael Gaitan

MEMS Project http://mems.nist.gov

September 9, 2003 NSA Visit



CSTL



John Kasianowicz, Biophysicist Protein Nanopores




Laurie Locascio, Biomedical Engineer Microfluidic Systems



John Marino, Biochemist NMR Proteins

PL



Lori Goldner, Physicist Nano-Optics



Angela Hight Walker, Chemical Physicist Molecular Spectroscopy




David Nesbitt, Chemical Physicist Single Biomolecule Fluorescence

EEEL



Michael Gaitan, Electrical Engineer MEMS and Nanofabrication



John Moreland, Physicist Nano-Magnetics and MEMS






Vince Stanford, Mathematician Signal Analysis



NIH



SM³ Program Objective

To develop and integrate new measurement methods to transport and probe structure, function, and dynamics of single biomolecules

DNA, RNA, and Proteins

NIST Role Measurements and Standards

Industry trend is smaller sample size

- genomics
- proteomics
- microfluidic systems
- lab-on-a-chip
- chem/bio sensors



Gene Chip

SM3 Deliverables

Measurement

- methods
- platform
- protocols
- standards
- data



\$1B Proposed for DNA Testing Washington Post, March 12, 2003

Measurement Challenge

Complete structural and functional measurements on single molecules.


How to isolate them?

How to measure them?

Technical Approach NanoBioTechnology Platform

Platform based on Nanofabrication Molecular Assembly

Manipulation (Transport): Fluidic Restrictions, Beads





Measurements: Electronic, Optical, Force

Manipulation (Capture): Vials, Beads, Arrays


Manipulation and Measurement

Electronic ... Optical ... Mechanical







Protein Nanopores




Data Analysis Decoding Algorithms



- Identical length DNA molecules cause different signals
- Signal content depends on the transport direction
- Building computer systems & software to decode information in molecules




Protein Nanopores




S. aureus aHL

B. anthracis PA₆₃


Solid State Nanopores






Electroplated

Single Molecule Optical Measurements









Activity of surface attached biomolecules

Dye molecules in polystyrene


RNA on biotinylated glass






A. 2 μm

B.



Simultaneous force and optical measurements: antibody/antigen interactions




Example: Alexa fluor 488 attached to glass. Anti-alexa attached to AFM tip. Anti-alexa quenches the fluorophore.


Single Molecule Vibrational Spectroscopy **Surface Enhanced Raman Scattering (SERS)**

Enhancement of Raman cross section can be as large as 10¹⁵ thereby permitting single molecule detection, however, nanostructure morphology, concentration, material, etc. are all critical to obtaining reproducible SERS substrates.


Goal: Quantitative SERS



Magnetic Cobalt Nanoparticles



Need gold-coated Co nanoparticles for SM sensitivity and magnetic manipulation




Vibrational Spectroscopy in situ in a MEMS device


Concentrate on low frequency vibrational modes--detailed structural info!!

E. Smith, Glascow

Magnetic bead trapping and position control



Trapping magnetic beads



Florescence microscopy video of magnetic beads coated with FITC dye near NiFe magnetic traps with and without applied field ($H_{bias} = 1 \text{ kOe}$).

Nanovials - Liposomes

DLPC (C_{12})

 $DMPC \quad (C_{14})$


DPPC (C_{16})

©Avanti Polar Lipids


Disperse in water and vesicle formation is

spontaneous







Spherical vesicle



LiposomesNanoreaction Vials




Reactants encapsulated in single liposome or in 2 separate liposomes and fused




Independently controllable environment, study reaction kinetics, single molecule events

Liposomes

Nanochannels




Pull a nanochannel from a liposome




Independently controllable environment, study reaction kinetics, single molecule events

Cellular BioElectronic Interfaces




Patterning PDMS with PEMS




Two weeks growth of retinal cells on poly(ethyleneimine).


Cells are covering all the polycation area.




Non-Patterned Cell Growth vs. Patterned Cell Growth



Retinal cells cultured in polystyrene culture flasks.



Overnight growth of retinal cells on poly(allylamine hydrochloride) patterned lines.



http://sm3.nist.gov